

# **GIRTON CAN RINSER-STERILIZER MODEL CR10SS**

## **CONSTRUCTION**

Girton Can Rinser-Sterilizers are ruggedly constructed with heavy gauge, stainless steel and are equipped with 3/4" NPT solid bronze valves. Water and steam connections can be made to either valve. Bases are drilled for easy bolting to the floor. The rinse basin is fabricated of stainless steel plate and tubing, designed with round bottom for strength and minimum water requirements. All seams are electrically welded and ground smooth. The standard basin is 12".

## **OPERATION**

A Girton Can Rinser-Sterilizer provides three separate cleaning treatments. With a can inverted over the basin-shaped top, simply depressing the right pedal gives you a cold-water pressure pre-rinse. By stepping on both pedals together, you get a hot water wash-rinse, and use of the left pedal alone give you a steam sterilization.

The big specially perforated nozzle directs a hard spray against the full inside surfaces of the can. Foot pedal operation leaves the operator's hands free to handle the cans.

# ***Can Rinser/Sterilizer***

